



chlebník
YM 100W



chlebník lesklý
ES 16310



chlebník matný
ES 16310



chlebník
YM 100



mlynček
YM 317



dóza nerez
YM 323



mlynček
YM 357



dóza
YM 328



dóza
YM 365M



dóza
YM 365L



dóza
YM 325S



dóza
YM 325M



koreničky
HK 307



koreničky
HK 308



HK 204



HK 203



cukornička
ES 07308



solnička+korenička
ES 07820



ES 07041



koreničky sklo, nerez
ES 07435



koreničky nerez
ES 07440



koreničky sklo, nerez
ES 07424



EW7 07133



EW7 07131S



EW7 07131C



držiak na vajce
YM 206



obruč na servítky
YM 211



odkvapávač
ES 07001



odkvapávač
EW7 15201



odkvapávač
ES 07117



misky so zásobníkom na napichovátka akryl
YY - 230



pohár na zmrzlinu akryl
YY - 138



stojan na príbor
EW7 04307



odkvapávač
EW32-07092



hodiny
YM 261



hodiny
YM 262



teleskopický stojan
LF 3008



misa
EW 1109



misa
YM F010



fondue
YM 415



Fondue
YM - 403



cukornička, akryl
YY - 142



miska
YY - 222



miska
YY - 223



dóza
YM 305



zásobník na servítky
YM 207



teleskopický stojan
LF 3084



zásobník na servítky
ES 03216



príborník
ES 07201



dóza plast
YY 203 S
10 x 9 cm,

dóza plast
YY 203 M
10 x 14 cm,

dóza plast
YY 203 L
10 x 18 cm,



dóza plast
YY 203 XL



krhlička
YM 020A



regál teleskop
LW 3013
20 x 60 x 60-80



držiak na papierové utierky
P 72